



NSX®

Quick Start Guide

Simrad NSX® multi-function display (MFD) is available in multiple sizes. This document describes the basic controls of the unit.


For the latest version of this document and other app guides, we recommend you download the Simrad mobile app, scan the QR code®, and connect with your NSX®, or visit: www.simrad-yachting.com/downloads/nsx.

→ **Note:** Refer to the enclosed Installation Manual before you turn on the unit.

BASIC CONTROLS

To turn the unit on, press and hold the power button (A). A beep indicates the unit is powering up.

To turn the unit off, press and hold the power button, or select Power off from the quick access menu.



- A Power button
- B Touchscreen

POWER CONTROL

Power to the unit can be controlled by an external switch or other units. For details about available power options, refer to the unit's installation manual.


→ **Note:** If your MFD is controlled by an external power source, it can't be powered off using the power button. Pressing and holding the power button puts the unit in standby mode. To wake the unit, press the power button again.

FIRST STARTUP

When you start the unit for the first time, or when you start it after a factory reset, you need to complete the initial setup for language, country, timezone, scan for an existing boat network, and follow the on screen prompts.

SETUP GUIDE

On the Welcome screen, select Continue device setup to complete the device settings. Alternatively, select the settings icon then select Setup guide.



→ **Note:** It is important to set up the MFD to ensure accurate navigation and safe operation.

QUICK ACCESS MENU

The quick access menu gives you immediate access to basic system settings and features. Press the power key or to display the quick access menu.




→ **Note:** To hide the quick access menu, swipe up or tap anywhere on the screen.

APPS AND STATUS BAR

An app is a program for a unique feature or function. The availability of some apps depends on the size of your unit and the hardware that is connected.

For app-specific user guides, download the Simrad app on your mobile device and connect it to your display unit, or visit: www.simrad-yachting.com/downloads/nsx.

Select to open the App drawer, where you can launch apps and access system settings. The status bar at the top of the screen shows live system status and alerts.




- A Home — select to view the App drawer
- B App drawer — a grid layout of all system and custom apps
- C Device status — displays status of connected devices such as radar or autopilot
- D Alerts — select to view recent and historic system alerts
- E Settings — select to view MFD settings
- F System status— displays system level indicators such as GPS lock, controllers, and internet connection

EMERGENCY AND MOB

Use the crew overboard (MOB) app for emergency situations. To activate a MOB, select the MOB icon (1) in the quick access menu to immediately create a MOB waypoint at your vessel's current location and begin.

Alternatively, open the MOB app (2). This automatically creates a MOB waypoint at your vessel's current location.

After the MOB is activated, select and follow the on-screen instructions to respond to the emergency.




→ **Note:** Select Stop Navigation to end MOB navigation. You

can then remove the MOB.

ALERTS

The unit continuously monitors connected sensors and devices for alerts, system faults and environmental changes. Alerts display on the top left of your screen and can be configured by setting up rules

To view a list of all your alert messages, select then on the quick access menu.



When triggered, an alert rule generates one of the following message types:

- Alarm** (red)—a message that stays on the screen until you mute it. If your system's siren is on, it is also accompanied by an audible alarm.
- Warning** (amber)—a message that stays on the screen until you mute it.
- Notification** (blue)—an informational message used to notify of a non-critical event e.g. software updates.

CONNECT TO MOBILE APP

Select Connect to Simrad mobile app from the quick access menu to connect your mobile device (phone or tablet) to the unit.

Download the Simrad app from the App Store® or Google Play®, then scan the QR code®.

Once connected, you can use the mobile app to:

- View and download app guides on your mobile device
- Register your display unit
- Subscribe to Premium charts
- Create your own waypoints, routes and tracks
- Explore points of interest (POI)
- Monitor marine traffic and weather
- Read the latest tips and tricks
- Download and apply software updates to the display unit

→ **Note:** An internet connection is required for most of the