
IDS Experience-Based Interface Quick Guide

EN

Panel overview



- **A** Home page button
- **B** Application panel
- **C** Panel buttons
- **D** Activity bar
- **E** Control bar
- **F** Instrument bar
- **G** Edit activity button

Panel buttons

Tap the application panel to display buttons. Panel buttons depend on application and disappear when no panel interaction occurs over time.

Menu button

Overlay button

Cursor button: activate and clear cursor


Orientation button

Activity modes

To open an activity mode: select a button on the activity bar.

An activity mode displays apps based on the predefined settings for an activity.


The Home page



- **A** Settings button
- **B** Toolbar
- **C** Application buttons
- **D** Status bar
- **E** Close button
- **F** System Controls button
- **G** Favorites
- **H** Man Over Board (MOB) button

The MOB mark

To create a MOB mark: press the MOB button.



To stop displaying navigational information to the MOB waypoint: cancel the navigation from the menu.

The System controls dialog

Used for quick access to system settings.

Activate the dialog by:


- Pressing the System Controls button.
- Swiping from the top of the screen.



➔ ***Note:*** Available icons depend on connected equipment and active panel.

Charts

- Zoom the chart by using spread or pinch gestures or by using the zoom buttons.
- Move the view in any direction by panning the chart.
- Display information about a chart item by tapping the item.




Waypoints

To create a waypoint: select the new waypoint option in the menu.

➔ ***Note:*** With cursor inactive, the waypoint is placed at vessel's position. With cursor active, the waypoint is placed at selected cursor position.


Echosounder

- Zoom the image by using the zoom buttons.
- View echosounder history by panning the image.
- Adjust gain and color using the slide bar in the menu.
- Toggle auto gain ON/OFF from the menu.




Autopilot

- Activate the autopilot controller from the Control bar.
- Select an autopilot mode by pressing the mode button from the Control bar.
- Switch to standby mode from the autopilot controller or by using the physical Standby key.



Radar

- Turn the radar transmitting ON/OFF from the menu.
- Adjust radar range by using the zoom buttons on the radar panel.



Product manuals

For the full User manual, technical specifications and declarations, refer to the product website on: www.simrad-yachting.com.